





DODGE RAM SIDE STEP
ESTRIBO DODGE RAM
ESQUIVER LE MEMOIRE RAM




C REG 8X
QUAD 12X
CREW 12X



D REG 8X
QUAD 12X
CREW 12X



E



REG

Lubricate the riv-nut tool by dipping the tool into the lubrication mixture of 1 part liquid dish detergent in 10 parts of water


Screw riv-nut tool pt# 82212003 into the riv-nut until finger tight.

Apply 25 Nm of torque to the riv-nut tool. If a torque wrench is not available rotate the riv-nut tool for 3.5 turns +/- 0.25 turn to ensure riv-nut is fully collapsed.

Important: Upon installation riv-nut flange should be flat and tight to the sheet metal. Riv-nut should not have any slack.

Caution: Use riv-nut tool pt# 82212003 to properly install riv-nuts. Do not use any other method to collapse riv-nuts.

Re-lubricate the riv-nut tool before installing every rivnut.



Torque: Bolts - 17 FT.LBS (23 Nm)

1

QUAD/CREW

Lubricate the riv-nut tool by dipping the tool into the lubrication mixture of 1 part liquid dish detergent in 10 parts of water


Screw riv-nut tool pt# 82212003 into the riv-nut until finger tight.

Apply 25 Nm of torque to the riv-nut tool. If a torque wrench is not available rotate the riv-nut tool for 3.5 turns +/- 0.25 turn to ensure riv-nut is fully collapsed.

Important: Upon installation riv-nut flange should be flat and tight to the sheet metal. Riv-nut should not have any slack.

Caution: Use riv-nut tool pt# 82212003 to properly install riv-nuts. Do not use any other method to collapse riv-nuts.

Re-lubricate the riv-nut tool before installing every rivnut.



Torque: Bolts - 17 FT.LBS (23 Nm)

2



PASSENGER SIDE SHOWN
EI LADO del PASAJERO MOSTRADO
LE PASSAGER PREND PARTI MONTRE

