TOYOTA TUNDRA/HV 2022 - SEQUOIA HV 2023 - TRD PERFORMANCE AIR FILTER

Preparation

Part Number: PTR03-34220

Kit Contents

NOTE: Two (2) kits required for installation.

Item #	Quantity Reqd.	Description
1	2	Performance Air Filter
2	2	Warning Label
3		

Hardware Bag Contents

Item #	Quantity Reqd.	Description
1		
2		
3		

Additional Items Required For Installation

Item #	Quantity Reqd.	Description
1		
2		
3		

Conflicts

N/A

Recommended Tools

Personal & Vehicle Protection	Notes
Safety Glasses or Goggles	
Special Tools	**Notes**
Installation Tools	**Notes**
None	
Special Chemicals	**Notes**
VDC Approved Cleaner	Prep Solvent 70 or similar

General Applicability

MY22 and newer Tundra/HV and MY23 and newer Sequoia HV models

Recommended Sequence of Application

Item #	Accessory
1	
2	
3	

*Mandatory

Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Reqd.	Description
1		
2		
3		

Legend

STOP: Damage to the vehicle may occur. Do not proceed until process has been complied with.

OPERATOR SAFETY: Use caution to avoid risk of injury.


CAUTION: A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.

TOOLS & EQUIPMENT: Used in Figures calls out the specific tools and equipment recommended for this process.

REVISION MARK: This mark highlights a change in installation with respect to previous issue.

SAFETY TORQUE: This mark indicates that torque is related to safety.

REGULATORY MARK: This mark indicates the component is related to regulatory compliance



© 2026 Toyota Motor Sales, USA

Procedure

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.

1. Prepare the Vehicle and Parts.

(a) Check the box for contents and any damage.

(b) Open the vehicle hood.

(c) Familiarize yourself with the installation and components before beginning.

(d) Apply vehicle protection to prevent damage to painted surfaces.

(e) **NOTE:** Two (2) TRD Performance Air Filter kits (PTR03-34220) are required for a complete installation.




Fig. 2-1

2. Remove the Driver-Side Factory Air Filter.

(a) Unlatch the two (2) air filter housing clips (Fig. 2-1).




Fig. 2-2

(b) Lift the filter housing lid up to expose the factory air filter (Fig. 2-2).

(c) Remove the factory air filter from the filter housing and discard it.

© 2026 Toyota Motor Sales, USA

Procedure






Fig. 3-1


Fig. 3-2


Fig. 3-3

3. Install the Driver-Side TRD Air Filter.

(a) Insert the TRD air filter into the air filter housing with the deep side of the filter down in the housing (Fig. 3-1).

(b) Move the air filter housing lid into place and engage the two (2) tabs (Fig. 3-2).

(c) Re-latch the two (2) air filter housing clips (Fig. 2-1).

(d) Use a lint free cloth and a VDC-approved cleaner such as 3M Prep Solvent 70 or similar to clean the air filter housing lid (Fig 3-3).

© 2026 Toyota Motor Sales, USA

4. Install Passenger-Side Air Filter

(a) Repeat Steps 2-3 to install second TRD Performance Air Filter to the passenger-side air intake




Fig. 5-1

5. Apply TRD Air Filter Care Label

Note: Only 1 Label needs to be applied, discard additional labels.

(a) Use a lint free cloth and a VDC-approved cleaner such as 3M Prep Solvent 70 or similar to clean the under hood for application location A or B (Fig. 5-1).

(b) Orient label “upright” as indicated by arrows and apply the TRD air filter care label to the pre-cleaned area. (Fig. 5-1).

6. Finish the Installation.

(a) Remove the vehicle protection used to prevent damage to painted surfaces.

© 2026 Toyota Motor Sales, USA

Checklist - these points **MUST** be checked to ensure a quality installation.

Check:	Look For:
Accessory Function Checks	
☐ Air Filter Housing Lid	Air filter housing tabs are engaged
☐ Air Filter Housing Clips	Air filter housing clips engaged
☐ Air Filter Care Label	Air Filter Care Label placed in designated area
Vehicle Function Checks	
☐ After accessory installation and removal of protective cover(s), perform a visual inspection.	Ensure no damage (including scuffs and scratches) was caused during the installation process. (For PPO installations, refer to TMNA Accessory Quality Shipping Standard.)

© 2026 Toyota Motor Sales, USA