






GENUINE PARTS

INSTALLATION INSTRUCTIONS

DESCRIPTION:	Rear Bumper Protector															
APPLICATION:	Altima															
PART NUMBER:	999B1 U4000															
KIT CONTENTS:																
<table border="1"><thead><tr><th>Item</th><th>Qty.</th><th>Part Description</th></tr></thead><tbody><tr><td>A</td><td>1</td><td>Rear Bumper Protector</td></tr><tr><td>B</td><td>2</td><td>Spacers</td></tr><tr><td>C</td><td>1</td><td>90% Alcohol Prep Pads</td></tr><tr><td>D</td><td>1</td><td>Installation Instruction Replacement Template</td></tr></tbody></table>	Item	Qty.	Part Description	A	1	Rear Bumper Protector	B	2	Spacers	C	1	90% Alcohol Prep Pads	D	1	Installation Instruction Replacement Template	
Item	Qty.	Part Description														
A	1	Rear Bumper Protector														
B	2	Spacers														
C	1	90% Alcohol Prep Pads														
D	1	Installation Instruction Replacement Template														
TOOLS REQUIRED:																
<ul style="list-style-type: none">• Clean, Lint-Free Wiping Cloth• Masking Tape• 90% or greater alcohol/water mix																
PRE-INSTALLATION WARNINGS, CAUTIONS, CRITICAL STEPS, and NOTES:																
<ul style="list-style-type: none">• Dealer Installation Recommended. Instructions may refer to Service Manual.																
⚠ CAUTION																
<ul style="list-style-type: none">• Install the rear bumper protector only when the part & vehicle temperatures are between 60°F-110°F (16°C-43°C).• Do not wash or expose the vehicle to a wet environment for 24 hours after installing the rear bumper protector.																

Installation Procedure:







- 1) Clean vehicle area thoroughly with soap and water to remove any dirt or debris and allow to dry.
- 2) Bumper protector installation prep.
 - a) Open rear hatch
 - b) Using a clean lint-free cloth and 90% Isopropyl Alcohol prep pads, clean area of rear bumper where part will be installed.
 - c) Allow time to dry thoroughly.

CAUTION

- Failure to clean mounting surface properly may cause adhesive tape to have poor adhesion to vehicle.


- 3) Dry fit bumper protector on vehicle by aligning bumper protector centering arrow with tailgate latch.
- 4) Position spacer block so that edge of block is approximately in line with ends of ribs on bumper protector and arrow points toward front of vehicle.
- 5) Secure spacer block to bumper with masking tape.

Installation Procedure:




- 6) Prepare tape.
 - a) Remove part.
 - b) Peel back approximately 30mm on all tape liners.
 - c) Fold back all liners.
- 7) Re-align part to vehicle and lightly tack ends of bumper protector to vehicle.
- 8) Confirm center arrow alignment to vehicle and tight-fit to spacers. If necessary, un-tack bumper protector and repeat.
- 9) While holding part in position, remove rear tape liners.
- 10) Using clean, lint-free cloth, start at center and apply 15 lbs/in² of pressure along tape path.
- 11) Remove spacer blocks.

Installation Procedure:




12) Remove front tape liners by pulling at a low angle.




13) Using clean, lint-free cloth, start at center and apply 15 lbs/in of pressure along tape path.

14) To ensure adequate adhesion, re-apply 15 lbs/in² of pressure across entire part.



15) Gap to fascia around protector should match limit shown.



16) Remove protective film by pulling horizontally and discard.

17) Close rear hatch.

18) Do not expose vehicle to moisture for 24 hours.