





GENUINE PARTS

INSTALLATION INSTRUCTIONS

DESCRIPTION:		Splash Guard-Rear Kit	
APPLICATION:		Rogue	
PART NUMBER:		T99J2 6RR0D	
KIT CONTENTS:			
Item	Qty.	Part Description	Service Part Number
A	1	Splash Guard - Rear Right	T98J2 6RR0F
B	1	Splash Guard - Rear Left	T98J2 6RR0E
C	4	Screw (Phillips) M5 x 20 mm	14-51 00891
D	4	Spring Clip M5	12-41 0015U
E	2	Push Pin	15-53 05323
F	1	Installation Instruction Replacement Template	999V2 AW000



A



B



C



D



E

STOP Important: Read Before Installation

Dealer Installation Recommended.

WARNING
To avoid serious personal injury or property damage, read all installation cautions before attempting to install this accessory. The installation instructions provide the necessary procedures for a safe installation.

CUSTOMER INTERNET DOWNLOAD INSTRUCTIONS: Customer's Online Installation Instructions for Drift or Nissan models are available through Dealer Technical Support at www.Nissan-Technical.com respectively. From the home page, click on "Inside Publications" and select "Accessory Installations." Select your vehicle's model year. Then follow the instructions for your accessory.

DEALER ASSIST DOWNLOAD INSTRUCTIONS: Dealer technicians can locate the installation instructions for this accessory in **AREA 1** of the **TOOLBOX**. Always download and use latest version of the installation instructions.

Installation Instruction Replacement Template: 999V2 AW000 Rev. 04/08/2020

F


TOOLS REQUIRED:

- Drill
- 6mm (1/4") drill bit
- #2 Phillips head screw driver
- Mild soap / water mixture
- 10mm Socket and Drive
- Clean Rag


PRE-INSTALLATION WARNINGS, CAUTIONS, CRITICAL STEPS, and NOTES:

- These installation instructions are for the left side of the vehicle; the same procedure applies to the right side.
- Dealer Installation Recommended.


INSTALLATION PROCEDURE:



- 1) Remove one (1) M6 bolt and one (1) push pin from bottom of rear bumper behind wheel well as shown. Keep M6 bolt and discard push pin.




- 2) Pull rear bumper fascia outward and drill two (2) 6 mm (1/4") holes at the dimple marks shown.




- 3) Clean installation surface (shaded area) with mild soap/water mixture.

INSTALLATION PROCEDURE: (continue)




- 4) Install two (2) M5 spring clips.



- 5) Re-install M6 bolt in rear bumper.


NOTE:

Do not over tighten screw. Reference Tighten Torque: 5.4~6.2N-m {48~55 in-lb}




- 6) Align splash guard to vehicle and install one (1) push pin at bottom location.

INSTALLATION PROCEDURE: (continue)



- 7) Align splash guard to vehicle and loosely install two (2) M5 screws.

NOTE:
Do not tighten screws at this time.



- 8) Push splash guard upward and inward towards vehicle and tighten screws in sequence shown.

NOTE:
Do not over tighten screws. Reference Tighten Torque: 3.8~4.4N-m {34~39 in-lb}

- 9) Repeat for passenger side of vehicle.