


REMOVAL

1 Remove shift selector finisher. Refer to [Removal and Installation](#).


2 Using a suitable tool, release clips and remove center console rear finisher (1).



GUID-TGALMIA0560ZZ



4 Remove screw (A) from center console bracket.



GUID-TGALJIA1066ZZ